

INSTALLATION INSTRUCTIONS

SINGLE PACKAGE AIR CONDITIONER - SINGLE STAGE, R-454B



IMPORTANT

ATTENTION INSTALLERS:

It is your responsibility to know this product better than your customer. This includes being able to install the product according to strict safety guidelines and instructing the customer on how to operate and maintain the equipment for the life of the product. Safety should always be the deciding factor when installing this product and using common sense plays an important role as well. Pay attention to all safety warnings and any other special notes highlighted in the manual. Improper installation of the furnace or failure to follow safety warnings could result in serious injury, death, or property damage.

These instructions are primarily intended to assist qualified individuals experienced in the proper installation of this appliance. Some local codes require licensed installation/service personnel for this type of equipment. Please read all instructions carefully before starting the installation. Return these instructions to the customer's package for future reference.

DO NOT DESTROY. PLEASE READ CAREFULLY & KEEP IN A SAFE PLACE FOR FUTURE REFERENCE.

TABLE OF CONTENTS

IMPORTANT SAFETY INFORMATION	2
REQUIREMENTS & CODES	4
Table 1.Required Air Flow , Maximum Charge Allowed, Required minimum Area of Conditioned space.....	4
GENERAL INFORMATION	4
Detecting Leaks of Flammable Refrigerants.....	5
Before You Install this Unit.....	5
Locating the Air Conditioner.....	5
Minimum Clearance Requirements.....	6
Air Duct System	6
Rooftop Installation	8
AIR CONDITIONER INSTALLATION	8
Unpacking the Unit.....	8
Installing Return & Supply Air Collars (Optional)	8
Supply Duct.....	8
Return Duct	8
Locating & Installing the Return Air Assembly	9
Connecting the Return & Supply Air Flexible Ducts.....	9
Locating & Installing the Supply Damper(s).....	9
Condensate Drainage	9
ELECTRICAL CONNECTIONS	10
Pre-Electrical Checklist.....	10
Line Voltage.....	10
Grounding	10
Overcurrent Protection.....	10
Table 2. Control Wiring (24V).....	10
Thermostat / Low Voltage Connections	11
Cooling Only Thermostat.....	11
Heat / Cool Thermostat	11
Blower Speed.....	11
START UP & ADJUSTMENTS	11
Pre-Start Checklist.....	11
Start-Up Procedure	11
Air Circulation	12
System Cooling	12
System Heating.....	12
AIR CONDITIONER MAINTENANCE	12
REFRIGERANT CHARGING	12
Charging the Unit	12
Removing Refrigerant and Evacuation	12
Refrigerant Recovery	13
Adjust Charges	13
If the outdoor temperature is above 65 degrees F or higher:.....	13
If the outdoor temperature is below 65 degrees F:	13
SAFETY SWITCHES	14
High Pressure Switch.....	14
A2L Refrigerant Leak Detection System.....	14
Table 2. Leak Detection Sensor LED Indications.....	14
Figure 10. Leak Detection Location.....	14
SERVICING	15
DECOMMISSIONING	15
FIGURES & TABLES	17
Figure 11. Unit Dimensions	17
Table 4. Physical Data	17
Table 5. Blower Data	18
Wiring Diagrams	19
Figure 12. Wiring Diagram (P95RD 2, 2.5, 3, 3.5 & 4 Ton Models).....	19
Figure 13. Wiring Diagram (P95RD 5 Ton Models).....	20
INSTALLATION CHECKLIST	21
REPLACEMENT PARTS	21

IMPORTANT SAFETY INFORMATION

Please read all instructions before servicing this equipment. Pay attention to all safety warnings and any other special notes highlighted in the manual. Safety markings are used frequently throughout this manual to designate a degree or level of seriousness and should not be ignored. **WARNING** indicates a potentially hazardous situation that if not avoided, could result in personal injury or death. **CAUTION** indicates a potentially hazardous situation that if not avoided, may result in minor or moderate injury or property damage.



**Refrigerant
Safety Group
A2L**

WARNING:

RISK OF FIRE. Dispose of properly in accordance with Federal or local regulations. Flammable refrigerant used.

WARNING:

RISK OF FIRE. Flammable refrigerant used. To be repaired only by trained service personnel. Do not puncture refrigerant tubing. Consult repair manual/owner's guide before attempting to service this product. All safety precautions must be followed.

WARNING:

RISK OF FIRE DUE TO FLAMMABLE REFRIGERANT USED. Follow handling instructions carefully in compliance with National regulations.

WARNING:

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

⚠ WARNING:

ELECTRICAL SHOCK, FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury, death or property damage. Improper servicing could result in dangerous operation, serious injury, death or property damage.

- Before servicing, disconnect all electrical power to the indoor blower.
 - When servicing controls, label all wires prior to disconnecting. Reconnect wires correctly.
 - Verify proper operation after servicing.
-

⚠ CAUTION:

This unit uses R-454B refrigerant. **DO NOT** use any other refrigerant in this unit. Use of another refrigerant will damage the unit.

⚠ WARNING:

These units are fully charged with R-454B refrigerant and ready for installation. When a system is installed according to these instructions, no refrigerant charging is required. If maintenance, service, or repair operations make it necessary for evacuation and charging, opening of sealed components, or opening of ventilated enclosures, then it should only be attempted by qualified, trained personnel that are thoroughly familiar with this equipment and have the appropriate training for working with A2L refrigerants. Under no circumstances should the equipment owner attempt to install and/or service this equipment. Failure to comply with this warning could result in equipment damage, personal injury, or death.

⚠ WARNING:

Do not place combustible material on or against the unit cabinet. Do not place combustible materials, including gasoline and any other flammable vapors and liquids, in the vicinity of the unit.

⚠ WARNING:

The information listed below must be followed during the installation, service, and operation of this unit. Unqualified individuals should not attempt to interpret these instructions or install this equipment. Failure to follow safety recommendations could result in possible damage to the equipment, serious personal injury or death.

- Before beginning the installation, verify that the unit model is correct for the job. The unit model number is printed on the data label.
- This equipment contains liquid and gaseous refrigerant under high pressure. **DO NOT USE ANY PORTION OF THE CHARGE FOR PURGING OR LEAK TESTING.** Installation or servicing should only be performed by qualified trained personnel thoroughly familiar with this type equipment.
- Installation of equipment may require brazing operations. Installer must comply with safety codes and wear appropriate safety equipment (safety glasses, work gloves, fire extinguisher, etc.) when performing brazing operations.
- This unit is designed for outdoor installations only and should be located in a position as shown on [page 6](#). Unit dimensions are shown in [Figure 11](#) & [Table 4](#), ([page 17](#)).
- The installer should become familiar with the units wiring diagram before making any electrical connections to the unit. See the unit wiring label or [Figure 12](#) ([page 19](#)) and [Figure 13](#) ([page 20](#)).
- Follow all precautions in the literature, on tags, and on labels provided with the equipment. Read and thoroughly understand the instructions provided with the equipment prior to performing the installation and operational checkout of the equipment.
- Use caution when handling this appliance or removing components. Personal injury can occur from sharp metal edges present in all sheet metal constructed equipment.
- Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.
- The appliance shall be stored in a room without continuously operating ignition sources (for example: open flames, an operating gas appliance or an operating electric heater. The appliance shall be stored so as to prevent mechanical damage from occurring.
- Be aware that refrigerants may not contain an odor.
- Do not pierce or burn.
- *P95RD-060K is equipped with electrically powered safety measures. To be effective, the unit must be electrically powered at all times after installation, other than when servicing. This requirement applies to units that are equipped with A2L Sensor Kit as well.

REQUIREMENTS & CODES

- All electrical wiring must be completed in accordance with local, state and national codes and regulations and with the National Electric Code (ANSI/NFPA 70) or in Canada the Canadian Electric Code Part 1 CSA C.22.1.
- The installer must comply with all local codes and regulations which govern the installation of this type of equipment. Local codes and regulations take precedence over any recommendations contained in these instructions. Consult local building codes and the National Electrical Code (ANSI CI) for special installation requirements.
- Air Ducts must be installed in accordance with the standards of the National Fire Protection Association “Standards for Installation of Air Conditioning and Ventilation Systems” (NFPA 90A), “Standard for Installation of Residence Type Warm Air Heating and Air Conditioning Systems” (NFPA 90B), these instructions, and all applicable local codes.

WARNING:

RISK OF FIRE. Auxiliary devices which may be a POTENTIAL IGNITION SOURCE shall not be installed in the duct work. Examples of such POTENTIAL IGNITION SOURCES are hot surfaces with a temperature exceeding 700° C and electric switching devices.

- Verify the required speed from the airflow data found in [Table 5, \(page 18\)](#). Place appropriate wire on the appropriate motor speed tap for the required airflow.
- Verify the unit air flow setting is greater than Required Minimum Air Flow Required Q_{min} in [Table 1](#).
- Verify installed conditioned area is greater than the Minimum Area of Conditioned Space, TA_{min} , in [Table 1](#).

- [Table 1](#), Leak Detection Device is optional for Shaded Model According to UL60335-2-40, 4th Edition, Table GG.1DV: if unit factory charge m_c lower than m_1 , No Refrigerant charge, room area and ventilation required
- In case of leak occurs, no additional ventilation required for installed conditioned area, unless conditioned area is less than TA_{min} in [Table 1](#). Consult manufacturer for assistance in this case.

GENERAL INFORMATION

- This packaged air conditioner is designed only for outdoor ground level installations and can be readily connected to the high static duct system of a home. This unit has been tested for capacity and efficiency in accordance with AHRI Standards, complying with PACKAGE UNIT requirements of UL 60335-2-40 or UL 1995, CSA 22.2 No 236 and will provide many years of safe and dependable comfort, providing it is properly installed and maintained. Abuse, improper use, and/or improper maintenance can shorten the life of the appliance and create unsafe hazards.
- To achieve optimum performance and minimize equipment failure, it is recommended that periodic maintenance be performed.
- This system contains R-454B, a mildly-flammable refrigerant. Consult the unit’s installation instructions and labels for more information.
- Prior to beginning work on this system, take steps to minimize the risk of refrigerant being ignited. These steps should include the following:
 - Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapor being present while the work is being performed. All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.

Model	Unit Factory Charge, m_c (Oz)	A2L Leak Detection Required? (Not Required if below m_1 , 63.7 Oz)	Minimum Airflow Required, Q_{min} (CFM)	Maximum Charge Allowed, m_{max} (Lbm) (Assume 1000 SqFt, 2.2m Room Height)	Maximum Charge Allowed, m_{max} (Lbm) (Assume 2000 SqFt, 2.2m Room Height)	Maximum Charge Allowed, m_{max} (Lbm) (Assume 5000 SqFt, 2.2m Room Height)	Required Minimum Area of Conditioned Space TA_{min} (Ft ²) (2.2m Room Height)
*P95RD-024K	37.0	No	62	68	136	339	34
*P95RD-030K	38.4	No	64	68	136	339	35
*P95RD-036K	34.0	No	57	68	136	339	31
*P95RD-042K	44.6	No	74	68	136	339	41
*P95RD-048K	46.7	No	78	68	136	339	43
*P95RD-060K	69.0	Yes	115	68	136	339	64

Note

- Leak Detection Device is optional for Shaded Model According to UL60355-2-40, 4th Edition, Table GG.1DV: if unit factory charge m_c lower than m_1 , No Refrigerant charge, room area and ventilation needed during installation.
- In case of leak occurs no additional ventilation required for installed conditioned area, unless conditioned area is less than TA_{min} in [Table 1](#). or system charge is more than maximum charge allowed under [Table 1](#). Consult manufacturer for assistance in this case.

Table 1. Required Air Flow , Maximum Charge Allowed, Required minimum Area of Conditioned space per UL60335-2-40 Annex GG

- o The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.
- o If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.
- o No person carrying out work in relation to a refrigerating system which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.
- o Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- o Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.
- o Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.
Initial safety checks shall include:
 - that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
 - that no live electrical components and wiring are exposed while servicing the unit;
 - that there is continuity of earth bonding
 - sealed components and intrinsically safe components shall be replaced instead of trying to repair them

Detecting Leaks of Flammable Refrigerants

- Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.
- The following leak detection methods are deemed acceptable for all refrigerant systems.
 - o Electronic leak detectors may be used to detect refrigerant leaks but, in the case of FLAMMABLE REFRIGERANTS, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used. Leak detection equipment shall

be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed.

- o Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.
- o NOTE Examples of leak detection fluids are:
 - bubble method,
 - fluorescent method agents.
 - If a leak is suspected, all naked flames shall be removed/extinguished.
 - If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak. Removal of refrigerant shall be according to the "Removing Refrigerant and Evacuation" section of this document.

Before You Install this Unit

- √ The cooling load of the area to be conditioned must be calculated and a system of the proper capacity selected. It is recommended that the area to be conditioned be completely insulated and vapor sealed.
- √ Check the electrical supply and verify the power supply is adequate for unit operation. If there is any question concerning the power supply, contact the local power company.
- √ All units are securely packed at the time of shipment and upon arrival should be carefully inspected for damage prior to installing the equipment at the job site. Verify coil fins are straight. If necessary, comb fins to remove flattened or bent fins. Claims for damage (apparent or concealed) should be filed immediately with the carrier.
- √ Please consult your dealer for maintenance information and availability of maintenance contracts. Please read all instructions before installing the unit.

Locating the Air Conditioner

- Survey the job site to determine the best location for mounting the outdoor unit. Select a solid, level position, preferably on a concrete slab, slightly above the grade level, and parallel to the home. If possible, select a site for the unit that is as close as possible to the proposed return grille location. Unit dimensions are shown in [Figure 11](#) & [Table 4, \(page 17\)](#). **DO NOT PLACE UNIT UNDER THE HOME.**
- The unit should be located with consideration of minimizing the length of the supply and return ducts. If practical, place the air conditioner and its ducts in an area where they will be shaded from the afternoon sun, when the heat load is greatest.
- The length of the supply and return ducts should be kept to a minimum with no sharp radius bends.
- Overhead obstructions, poorly ventilated areas, and areas subject to accumulation of debris should be avoided. The hot condenser air must be discharged up and away from the home, and if possible, in a direction with the prevailing wind. Do not place the unit in a confined space. See [Figure 11](#) & [Table 4, \(page 17\)](#) for unit dimensions.
- Sufficient clearance for unobstructed airflow through the outdoor coil must be maintained in order to achieve rated performance.
- Consideration should also be given to availability of electric power, service access, noise, and shade.

Minimum Clearance Requirements

Sufficient clearance for unobstructed airflow through the outdoor coil must be maintained in order to provide room for proper servicing and achieve rated performance. See Figure 1 for minimum clearances to obstructions.

Service Access Clearance:

Blower and electrical control access panels.....	24"
Compressor compartment access panel.....	24"
Clearance from top of unit	72"
Clearance around condenser coil area to Wall or shrubs (excludes duct panel side).....	12"

Clearances to Combustibles:

Combustible base - wood or Class A, B, or C roof covering material.....	0"
Supply & return air ducts	0"
Duct connection side	0"

Air Duct System

Air ducts must be installed in accordance with the standards of the National Fire Protection Association "Standard for Installation of Air Conditioning and Ventilation Systems" (NFPA 90A), "Standard for Installation of Residence Type Warm Air Heating and Air Conditioning Systems" (NFPA 90B), these instructions, and all applicable codes. NFPA publications are available by writing to: National Fire Protection Association, Batterymarch Park, Quincy, ME 02269 or visit www.NFPA.org on the web.

- Design the duct work according to methods described by the Air Conditioning Contractors of America (ACCA).
- The supply duct system, including the number and type of registers, will have much more effect on the performance of the system than any other factor. The duct must be sufficiently large to conduct an adequate amount of air to each register. See Figure 2.

- Duct work should be attached directly to the unit flanges for horizontal applications.
- For highly resistive duct systems it may be necessary to add an additional return air duct and or supply to achieve maximum performance and prevent coil icing and refrigerant flood back.
- **The air conditioning output of the system will not cool the home if air is lost to the outside through leaks in the duct system. Ducts that are collapsed or restricted by foreign objects will also prevent adequate air flow.**
- All duct work passing through unconditioned space must be properly insulated to minimize duct losses and prevent condensation. Use insulation with an outer vapor barrier. Refer to local codes for insulation material requirements.




Figure 1. Minimum Unit Clearances




Figure 2. Single & Multiple Duct Applications

NOTE: Appropriate protection should be used between the strap and the sheet metal edge of the unit.




Figure 3. Slings and Bottom Channels

Rooftop Installation

Rooftop installations must follow local building codes or applicable safety codes and requirements:

- Prepare a supporting rack that is adequately designed to support and handle the unit weight and minimum wind loads. Reinforce the roof area for the installation if required. For unit weights, see [Table 4 \(page 17\)](#).
- The unit should be lifted using slings and spreader bars. Make sure the rigging slings and bars are in good shape and can withstand and handle the static and dynamic loads. Refer to [Table 4](#) for unit weights.
- The spreader bars are necessary for proper load stability and to prevent the unit's cabinet from being damaged. The slings should run thru the unit's bottom channels (see [Figure 3](#)) and should be adequately protected against cabinet metal edges. **NOTE:** Appropriate protection should be used between the strap and the sheet metal edge of the unit.
- The rigging must be located outside of the unit's center of gravity. Refer to [Figure 11 \(page 17\)](#) and [Table 4](#) for center of gravity locations.

CAUTION:

All panels must be securely in place when rigging and hoisting.

WARNING:

To avoid the risk of property damage or personal injury, it is the rigger's responsibility to ensure that whatever means are used to hoist the unit are safe and adequate.

WARNING:

Never hoist the unit over people or stand below the rigged unit. The roof top unit must remain in an upright position all the time.

AIR CONDITIONER INSTALLATION

Unpacking the Unit

It is recommended that the unit be unpacked at the installation site to minimize damage due to handling.

CAUTION:

Do not tip the unit on its side. Oil may enter the compressor and cause damage.

1. Remove the bands from around the unit.
2. Unfold the top and bottom cap flanges.
3. Carefully remove the top cap and tube.

Installing Return & Supply Air Collars (Optional)

Supply and return collars are not supplied with the unit but are offered as accessory item. Check with your distributor for pricing and availability. They can be easily positioned over the unit openings and secured with sheet metal screws. See [Figure 4 \(page 8\)](#).

- The diameter of the return duct collar is 12" for 1.5 - 3 Ton models, and 14" for 3.5 - 5 Ton models.
- The diameter of the supply duct collar is 12".
- Before permanently installing the collars, it is recommended you pre-fit them over the openings first to determine best fit and alignment.

Supply Duct

1. Assemble the collar by overlapping the two ends. **NOTE:** One end of the collar is slotted and the opposite end has two small holes. Position the end with small screw holes underneath the slotted end.
2. Fasten the collar ends with two self drilling sheet metal screws.
3. Position the collar over the opening and align the 4 holes in the collar with the 4 holes (or dimples depending on model) in the rear panel.
4. Using self-drilling screws (#10 - 16 x 0.5), secure the collar to the rear panel.

Return Duct

1. Assemble the collar by overlapping the two ends. **NOTE:** One end of the collar is slotted and the opposite end has two small holes. Position the end with small screw holes underneath the slotted end.
2. Fasten the collar ends with two self drilling sheet metal screws.
3. Position the collar over the opening. Align the four holes in the collar with the four dimples or holes (depending on unit model) in the panel.
4. Secure the collar to the rear panel using self tapping screws (#10 - 16 x 0.5).

Locating & Installing the Return Air Assembly

To simplify installation, locate and install the return air assembly first. If desired, the return opening can be located inside a closet with louvered doors that has an open area equal to or greater than a 12" x 20" grille. The return air grille can be placed in the wall of a closet and the air ducted into the filter box through a boxed-in area at the closet floor level ([Figure 5](#)). **Verify the filter is readily accessible.**

NOTE: The return air box with grille and filter should not be located in heavy traffic areas like hallways or center of rooms. A good spot is in a corner or under a table, if a minimum two inch clearance is available.

1. Start the installation from under the home by cutting a small hole in the sub-floor. Determine how the floor joist location will affect cutting the opening needed for the return air box. **NOTE:** Floor joists are generally located on 16" centers, leaving 14-3/8" between joists.




Figure 4. Return & Supply Air Collars




Figure 5. Return Air Box

2. After measuring the return air box (approximately 12-1/4" x 20-1/4"), cut the hole through the floor so that the box will fit between the floor joists. Care should be taken when cutting through carpeting to avoid snags. **NOTE:** In most installations it will be necessary to cut a similar hole in the fiberboard directly under the hole in the floor. However, if the floor is more than ten inches deep, it will only be necessary to cut a hole for the collar on the return air box or for the insulated duct.
3. Set the box into the opening and fasten with screws or nails.
4. Install the filter and return air grille in the air box.

Connecting the Return & Supply Air Flexible Ducts

- Flexible ducts may be cut to the required length and spliced with sheet metal sleeves and clamps. **Keep all ducts as short and straight as possible. Avoid sharp bends.** Please follow all instructions packed with duct.
- Flexible ducts can be secured to the corresponding fittings with the clamps provided with the ducts. **NOTE:** To prevent a loss in cooling capacity, make sure all connections are tight.
- Ducts may be spliced with sheet metal sleeves and clamps.
- After the inner duct is connected to the proper fitting, the insulation and plastic sleeve should be pulled over the connection and clamped.
- Homes with multiple supply ducts (or special applications), a Y fitting is available to divide the supply air so it can be ducted to different areas of the home for more efficient cooling. **NOTE:** For maximum performance, insulate the Y fitting.

Locating & Installing the Supply Damper(s)

CAUTION:

If installing this air conditioning system in conjunction with a furnace, a damper must be installed in the furnace base assembly to prevent cold air from being discharged around the heat exchanger. Damage to the heat exchanger and asphyxiation may occur if a damper is not installed.

Check with the furnace manufacturer for damper requirements. Failure to install the required furnace damper may invalidate code agency listing and limited warranty on the furnace.

When locating the supply damper(s), carefully check floor joists and frame members that could interfere with the installation of the damper or flexible duct. Ideally, the damper should be located in the bottom of the main duct, forward of center of the home, at least three feet from the nearest register. See [Figure 6](#). The round supply opening in the slanted side of the damper should face the side of the home where the air conditioner is located.

1. Locate the center of the heat duct by cutting a small hole in the fiberboard below the duct at the desired location.
2. Cut a hole approximately 3/4" larger than the damper opening in the fiberboard.
3. Cut a 9-1/8" x 13-1/8" hole in the duct and bend over all tabs flat on the inside of the heat duct.
4. Insert the damper into the duct and bend over all tabs flat on the inside of the heat duct.
5. Seal the opening between the fiberboard and damper or flexible duct.

Condensate Drainage

A 3/4" condensate fitting extends out of the side of the unit ([Figure 7](#)). The drain trap, shipped in the electrical compartment, must be installed to prevent water from collecting inside the unit.

1. Thread the elbow provided with the unit into the drain connection until hand tight.
 2. Connect the condensate tubing onto the fitting, forming a trap near the drain connection.
 3. Route the condensate tube from the trap to a suitable drain.
- NOTE:** For proper drainage, make sure the trap is level to the ground and tubing outlet is below trap level.




Figure 6. Supply Damper




Figure 7. Drain Trap

ELECTRICAL CONNECTIONS

WARNING:

Risk of electric shock, can cause injury or death, disconnect all remote electric power supplies to the unit before servicing.

- Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.
- All electrical wirings must be in accordance with local, state and national codes and regulations and with the National Electric Code (ANSI/NFPA 70) or in Canada the Canadian Electric Code Part 1 CSA C.22.1.

Pre-Electrical Checklist

- ✓ Verify that the voltage, frequency, and phase of the supply source match the specifications on the unit rating plate.
- ✓ Verify that the service provided by the utility is sufficient to handle the additional load imposed by this equipment. Refer to the unit wiring label for proper high and low voltage wiring.
- ✓ Verify factory wiring is in accordance with the unit wiring diagram [Figure 12 \(page 19\)](#) and [Figure 13 \(page 20\)](#). Inspect for loose connections.

Line Voltage

- A wiring diagram is located on the inside cover of the electrical box of the unit. The installer should become familiar with the wiring diagram before making any electrical connections to the unit.
- **An electrical disconnect must be located within sight of and readily accessible to the unit.** This switch shall be capable of electrically de-energizing the unit.
- Line voltage to the unit should be supplied from a dedicated branch circuit containing the correct fuse or circuit breaker for the unit. Incoming field wiring and minimum size of electrical conductors and circuit protection must be in compliance with information listed on the unit data label. Any other wiring methods must be acceptable to authority having jurisdiction.
- Provide power supply for the unit in accordance with the unit wiring diagram, and the unit rating plate. Connect the line-voltage leads to the terminals on the contactor inside the control compartment. Extend leads through power wiring hole ([Figure 8](#)). Connect L1 & L2 directly to the contactor.
- The unit requires both power and control circuit electrical connections. Refer to the wiring diagrams ([Figure 12 \(page 19\)](#) & [Figure 13 \(page 20\)](#)) for identification and location




Figure 8. Power Entry

of unit field wiring interfaces. Make all electrical connections in accordance with all applicable codes and ordinances.

- Use only copper wire for the line voltage power supply to this unit. Use proper code agency listed conduit and a conduit connector for connecting the supply wires to the unit. Use of rain tight conduit is recommended.
- 208/230 Volt units are shipped from the factory wired for 230 volt operation. For 208V operation, remove the lead from the transformer terminal marked 240V and connect it to the terminal marked 208V.
- Optional equipment requiring connection to the power or control circuits must be wired in strict accordance of the NEC (ANSI/NFPA 70), applicable local codes, and the instructions provided with the equipment.

Grounding

WARNING:

The unit cabinet must have an uninterrupted or unbroken electrical ground to minimize personal injury if an electrical fault should occur. Do not use gas piping as an electrical ground!

This unit must be electrically grounded in accordance with local codes or, in the absence of local codes, with the National Electrical Code (ANSI/NFPA 70) or CSA C22.1 Electrical Code. Ground the air conditioning unit using the green grounding screw provided in the control panel.

Overcurrent Protection

Overcurrent protection must be provided at the branch circuit distribution panel and sized as shown on the unit rating label and according to applicable local codes. Generally, the best fuse or

WIRE GAUGE	RECOMMENDED MAXIMUM WIRE LENGTH (FT) FROM UNIT TO THERMOSTAT
22	45
20	70
18	115
16	180

Table 2. Control Wiring (24V)




Figure 9. Low Voltage Connections

breaker for any heat pump is the smallest size that will permit the equipment to run under normal usage and provide maximum equipment protection. Properly sized fuses and breakers also prevent nuisance trips during unit startup.

NOTE: If a fuse blows or a breaker trips, always determine the reason. Do not arbitrarily install a larger fuse or breaker and do not, in any case, exceed the maximum size listed on the data label of the unit.

Thermostat / Low Voltage Connections

- The unit is designed to operate from a 24 VAC Class II control circuit. The control circuit wiring must comply with the current provisions of the NEC (ANSI/NFPA 70) and with applicable local codes having jurisdiction. Thermostat connections should be made in accordance with the instructions supplied with the thermostat and the indoor equipment.
- The low voltage wires must be properly connected. Route 24V control wires through the sealing grommet near the power entrance. See [Figure 8](#). Recommended wire gauge and wire lengths for typical thermostat connections are listed in [Table 2](#).
- Single stage or two-stage heating thermostats can be used with this equipment depending on optional accessories installed with the unit. Select a thermostat that operates in conjunction with the installed accessories.
- The thermostat should be mounted about 5 feet above the floor on an inside wall. DO NOT install the thermostat on an outside wall or any other location where its operation may be adversely affected by radiant heat from fireplaces, sunlight, lighting fixtures or convective heat from warm air registers or electrical appliances. Refer to the thermostat manufacturer's instruction sheet for detailed mounting information.

Cooling Only Thermostat

Connect the **red & black** wires from the unit to the **R & Y1** terminals on the thermostat subbase. Connect the **green** wire to the **green** wire at the unit. See [Figure 9](#).

Heat / Cool Thermostat

For the highest efficiency, the use of a 2-stage Heating/Cooling thermostat is recommended. The heat/cool thermostat prevents simultaneous operation of the heating and cooling units and is equipped with an ON-AUTO fan mode that allows the home owner to operate the indoor blower when only air circulation is desired. Connect the red, black, green and brown/orange low voltage wires to the **R, Y1, G, W2** terminals on the thermostat base. The black wire is the 24 volt common required on some thermostats. See [Figure 9 \(page 10\)](#).

Blower Speed

For optimum system performance and comfort, it may be necessary to change the factory speed setting. See [Table 5, \(page 18\)](#) for factory settings.

WARNING:

To avoid electric shock, personal injury, or death, turn off the electric power at the disconnect or the main service panel before making any electrical connections.

CAUTION:

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

CAUTION:

To avoid personal injury or property damage, make certain that the motor leads cannot come into contact with any metal components of the unit.

1. Disconnect all electrical power to the unit and remove the service panel.
2. Locate the black and red wires terminated to the blower motor.
NOTE: The black wire controls cooling operation and the red wire controls the heating operation.
3. Verify the required speed from the airflow data found in [Table 5, \(page 18\)](#). Place appropriate wire on the appropriate motor speed tap for the required airflow.
4. Check all factory wiring as shown in the wiring diagram and inspect the connections to make sure none of them loosened during shipping or installation.

START UP & ADJUSTMENTS

Pre-Start Checklist

The following check list should be observed prior to starting the unit.

- ✓ Verify the unit is level and allows proper condensate drainage.
- ✓ Verify the outdoor coil and top of the unit are free from obstructions and debris, and all equipment access/control panels are in place. Unit must be installed with the proper clearances shown in [Figure 1 \(page 6\)](#).
- ✓ Verify that the duct work is sealed to prevent air leakage.
- ✓ Verify that the line voltage power leads are securely connected and the unit is properly grounded. Check the condenser fan to make sure it turns freely.
- ✓ Verify the thermostat is wired correctly and installed in a proper location. Make sure the low voltage wires are securely connected to the correct leads on the low voltage terminal strip.
- ✓ Verify that the power supply branch circuit overcurrent protection is sized properly.
- ✓ To achieve rated capacity and efficiency the compressor must be exposed to refrigerant for at least 24 hours prior to running. After unit startup, the compressor must run for a minimum of 12 hours.

Start-Up Procedure

CAUTION:

If the unit is equipped with a crankcase heater, allow 24 hours prior to continuing the start up procedures to allow for heating of the refrigerant compressor crankcase. Failure to comply may result in damage and could cause premature failure of the system. This warning should be followed at initial start up and any time the power has been removed for 12 hours or longer.

The control circuit thermostat may consist of an anti-short cycle timer that will not let the compressor re-start before 5 minutes have elapsed.

1. Set the system mode to OFF and the temperature mode to its highest setting.
2. Turn power on at the disconnect switch.
3. Set the system mode to ON or COOL.
4. Set the temperature mode below room temperature. Verify that the indoor blower, outdoor fan, and compressor energize and the cooling function starts.
5. Verify the discharge air grilles are adjusted and the system air is balanced.
6. Verify the duct work has no air leaks.
7. Verify the condensate drain is installed correctly and functions properly.
8. Set the temperature mode above room temperature. The unit should stop.
9. Instruct the homeowner on unit and thermostat operation and filter servicing.

Air Circulation

Leave the thermostat system mode on OFF, and set the fan mode to ON. Blower should run continuously. Check the air delivery at the supply registers and adjust register openings for balanced air distribution. Examine ducts for leaks or obstruction if insufficient air is detected.

Set the thermostat fan mode to AUTO. The blower should stop running.

System Cooling

Set the thermostat's system mode to COOL and the fan mode to AUTO. Lower the thermostat temperature selector below the existing room temperature. Allow the cooling system to operate for several minutes and check for the discharge of cool air at the supply registers.

System Heating

(Available only when Electric heat is supplied) Set the thermostat's system mode to HEAT and the fan mode to either AUTO (intermittent air) or to ON (continuous air). Raise the thermostat's temperature selector above the existing room temperature and check the following:

1. The compressor and outdoor fan should not run.
2. The blower will run according to the thermostat's fan mode setting.

AIR CONDITIONER MAINTENANCE

WARNING:

To prevent electrical shock, personal injury, or death, disconnect all electrical power to the unit before performing any maintenance or service. The unit may have more than one electrical supply.

Proper maintenance is important to achieve optimum performance from the air conditioner. The ability to properly perform maintenance on this equipment requires certain mechanical skills and tools. If you do not possess these skills, contact your dealer for maintenance. Consult your local dealer about the availability of maintenance contracts.

Routine maintenance should include the following:

- Inspect and clean or replace air filters at the beginning of each heating and cooling season, or more frequently if required.

- Inspect the condensate drain and outdoor coil at the beginning of each cooling season. Remove any debris. Clean the outdoor coil and louvers as necessary using a mild detergent and water. Rinse thoroughly with water.
- Inspect the electrical connections for tightness at the beginning of each heating and cooling season. Service as necessary.

CAUTION:

The unit should never be operated without a filter in the return air system. Replace disposable filters with the same type and size.

- Do not add additional oil to motors unequipped with oil tubes. The compressor is hermetically sealed at the factory and does not require lubrication.

REFRIGERANT CHARGING

Charging the Unit

CAUTION:

This air conditioner contains liquid and gaseous refrigerant under pressure. Adjustment of refrigerant charge should only be attempted by qualified, trained personnel thoroughly familiar with the equipment and safe responsible refrigerant handling procedures. Under no circumstances should the homeowner attempt to install and/or service this equipment. Failure to comply with this warning could result in equipment damage, personal injury, or death.

Removing Refrigerant and Evacuation

- When breaking into the refrigerant circuit to make repairs – or for any other purpose – conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed, since flammability is a consideration. The following procedure shall be adhered to:
 - o Safely remove refrigerant following local and national regulations
 - o Evacuate the system
 - o Purge the circuit with inert gas (optional for A2L)
 - o Evacuate the system (optional for A2L)
 - o Continuously flush or purge with inert gas when using flame to open circuit and
 - o Open the circuit

The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes. For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times. Compressed air or oxygen shall not be used for purging refrigerant systems.

For appliances containing flammable refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum (optional for A2L). This process shall be repeated until no refrigerant is within the system (optional for A2L). When the final oxygen-free nitrogen charge is used,

the system shall be vented down to atmospheric pressure to enable work to take place.

The outlet for the vacuum pump shall not be close to any potential ignition sources, and ventilation shall be available.

Refrigerant Recovery

WARNING:

Recovering refrigerant involves breaking into the refrigerant circuit. It should only be attempted by qualified trained personnel thoroughly familiar with this equipment. Under no circumstances should the owner attempt to do this work. Failure to comply with this warning could result in property damage, personal injury, or death.

- **When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.**
- **When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available. All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.**
- **The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of the flammable refrigerant. If in doubt, the manufacturer should be consulted. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak free disconnect couplings and in good condition.**
- **The recovered refrigerant shall be processed according to local legislation in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.**
- **If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The compressor body shall not be heated by an open flame or other ignition sources to accelerate this process. When oil is drained from a system, it shall be carried out safely.**

NOTE: The refrigerant charge can be checked and adjusted through the service ports provided external to the unit. Use only gage line sets which have a “Schrader” depression device present to actuate the valve.

The following additional requirements shall be followed due to the mildly flammable refrigerant used in this system.

- Recovering refrigerant involves breaking into the refrigerant circuit. It should only be attempted by qualified trained personnel thoroughly familiar with this equipment. Under no circumstances should the owner attempt to do this work. Failure to comply with this warning could result in property damage, personal injury, or death.
- Ensure that the refrigerating system is earthed prior to charging the system with refrigerant.
- Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
- Cylinders shall be kept in an appropriate position according to the instructions.
- Label the system when charging is complete (if not already).
- Extreme care shall be taken not to overfill the refrigerating system.
- The system shall be leak-tested on completion of charging but prior to commissioning, the pressure must never exceed 450 psig or the compressor may be damaged and the warranty voided. A follow up leak test shall be carried out prior to leaving the site.
- The recovered refrigerant shall be processed according to local legislation in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.

Adjust Charges

If the outdoor temperature is above 65 degrees F or higher:

Charge the system following the steps below:

1. With the system operating at steady state, measure the superheat at suction line service valve.
2. Measure the outdoor dry bulb temperature (°F) and indoor wet bulb temperature (°F).

NOTE: The charging tables are on the inside of the unit’s electrical control access panel. The tables provide superheat targets for the units.

3. Adjust the charge to match the target superheat.
4. The system should be charged so that the measured superheat is within +/- 1°F of the target listed in the table.

Note:

- If your measured superheat at the suction valve is **LESS THAN** the recommended superheat value in the table then **REMOVE** refrigerant.
- If your measured superheat at the suction valve is **GREATER THAN** the recommended superheat value in the table then **ADD** refrigerant.

If the outdoor temperature is below 65 degrees F:

After leak checking the system, and evacuating the system, perform the following steps:

1. weigh in the charge amounts recommended and printed on the unit rating plate, the rating plate can be found on the exterior panel of the unit.
2. Return to the system when the outdoor temperature is 65 degrees F or higher and follow the steps defined at “If the outdoor temperature is 65 degrees F or higher” section above.

SAFETY SWITCHES

High Pressure Switch

The high-pressure switch is factory-installed and located in the liquid line internal to the unit. The switch is designed to protect the system when very high pressures occur during abnormal conditions. Under normal conditions, the switch is closed. If the liquid pressure rises above 650 psig, the switch will open and de-energize the unit. The switch will close again when the liquid pressure decreases to 460 psig.

A2L Refrigerant Leak Detection System (only applies to 5 Ton Units or units that are installed with A2L Sensor Kit)

The A2L refrigerant leak detection sensor is factory-installed, leak tested and is located in the blower department internally at the supply air side to the unit. See Figure 10 shown the leak detection sensor location inside of the unit.

The sensor is designed to detect a refrigerant leak within the atmosphere around the sensor. Sensor is powered by the secondary side of the transformer, see Wiring Diagram for details. Figure 12 & 13 (Page 19 & 20).

The following cautions shall be taken while servicing the unit due to the mildly flammable refrigerant used in this system.

- The wiring diagram is shown with the sensor in the alarm state (Relays are in normally closed state).
- Ensure that if an A2L sensor is not connected, that the system will not operate.
- When a leak is detected, the double relay output sensor will switch both of the internal relays: This will disable the low voltage power supply to the unit, so compressor or heater kits will not run; at the same time, sensor relay will switch on an alarm output for alarm or light (Terminal strip "AL" terminal); and turn on the blower with cooling (High) speed once leak is detected.
- The blower will remain on for 5 minutes after the leakage is no longer detected. It is possible the blower will cycle on and off a few times if a small amount of leakage is present.
- Refrigerant sensor for refrigerant leak detection shall only be replaced with sensor specified by NORTEK.

- When the sensor reaches the end of life, it will transition into fail-safe state and this state is irreversible. When triggered by end-of-life diagnostics, a simple power cycle will not recover the sensor, it will need to be replaced.
- The leak detection sensor equipped with two LEDs, a red and a green one, offers a visual representation of the state the leak detector is currently operating in. Refer to Table 3 for LED indications.

LEAK DETECTION SENSOR STATUS	LED	LED STATE
Power up Warm up	Green	On, steady
Normal Operation	Green	Heartbeat
Power Up Fail	Amber	On, steady
Near End Of Life	Green & Red	Blinking
End of Life Replace Sensor	Red	Blinking
Internal Diagnostic Fail *	Red	Blinking
DTLV Alarm	Red	On, steady
WARNING Out of Operating Range	Green & Amber	Heartbeat

* A power cycle on the sensor will be able to reset an internal sensor fault.

LED PATTERN	ON-TIME	OFF-TIME
ON	100%	0%
Blinking	50%	50%
Heartbeat	20%	80%

When Blinking or for the Heartbeat, the LED's flash at approximately once per second.

Table 3. Leak Detection Sensor LED Indications




Figure 10. Leak Detection Sensor Location

SERVICING

WARNING:

- **Work procedure** Work shall be undertaken under a controlled procedure so as to minimise the risk of a flammable gas or vapor being present while the work is being performed.
 - **No ignition sources** No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. “No Smoking” signs shall be displayed.
 - **Checks to the area** Prior to beginning work on systems containing FLAMMABLE REFRIGERANTS, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the REFRIGERATING SYSTEM, DD.4.3 to DD.4.7 shall be completed prior to conducting work on the system.
 - **General work area** All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.
 - **Checking for presence of refrigerant** The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.
 - **Presence of fire extinguisher** If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.
 - **Ventilated area** Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
- **Checks to the refrigerating equipment** Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer’s maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer’s technical department for assistance.
 - **Repairs to sealed components** Sealed electrical components shall be replaced.
 - **Repair to intrinsically safe components** Intrinsically safe components must be replaced.

DECOMMISSIONING

WARNING:

Decommissioning the system involves breaking into the refrigerant circuit. It should only be attempted by qualified trained personnel thoroughly familiar with this equipment. Under no circumstances should the owner attempt to do this work. Failure to comply with this warning could result in property damage, personal injury, or death.

- It is recommended good practice that all refrigerants are recovered when possible.
- **Before decommissioning the system:**
 - Become familiar with the equipment and its operation.
 - Take a sample of oil and refrigerant in case analysis is required prior to re-use of recovered refrigerant.
 - Ensure that electrical power is available for use in the decommissioning operations
 - Ensure that mechanical handling equipment is available, if required, for handling refrigerant cylinders.
 - Ensure that all personal protective equipment (PPE) is available and being used correctly.
 - Ensure that the recovery process is supervised at all times by a competent person.
 - Ensure that the recovery equipment to be used and refrigerant cylinders conform to the appropriate standards.
 - Position the recovery cylinder on the scales before recovery of refrigerant begins.
 - **Procedure for Decommissioning System:**
 1. Isolate the system electrically.
 2. Pump down the refrigerant system, if possible.
 3. If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.

- 4. Start the recovery machine and operate it in accordance with its instructions. Refer to the Refrigerant Recovery section of this document for additional information.**
 - 5. Do NOT overfill cylinders (no more than 80% volume liquid charge).**
 - 6. Do NOT exceed the maximum working pressure of the cylinder, even temporarily.**
 - 7. When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.**
 - 8. Recovered refrigerant shall not be charged into another refrigerating system unless it has been cleaned and checked.**
 - 9. Label the system stating that it has been decommissioned and emptied of refrigerant. The label shall be dated and signed. Ensure that there are still labels on the equipment stating that the system contains flammable refrigerant to properly identify it.**
-

FIGURES & TABLES




Figure 11. Unit Dimensions

P95RD MODEL	LENGTH -L-	WIDTH W	HEIGHT -H-	-A-	-B-	-CG1-	-CG2-	SHIPPING WEIGHT (LBS)	NET WEIGHT (LBS)
024K	49	35	22.2	35.02	2.48	18.1	14.8	200	212
030K	49	35	22.2	35.02	2.48	18.1	14.8	225	237
036K	49	35	22.2	35.02	2.48	18.1	14.8	231	243
042K	49	35	30.2	35.02	2.48	18.7	14.3	282	296
048K	49	35	30.2	35.02	2.48	18.7	14.3	298	284
060K	63	35	38.2	35.02	2.48	23.5	14.0	337	353

Table 4. Physical Data

HEAT RISE DATA (BASED ON NOMINAL 10KW ELECTRIC HEAT KIT)																	
P95RD UNIT	BLOWER SETTING	EXTERNAL STATIC PRESSURE DROP - INCHES WATER COLUMN															
		0.1		0.2		0.3		0.4		0.5		0.6		0.7		0.8	
		CFM	HEAT RISE	CFM	HEAT RISE	CFM	HEAT RISE	CFM	HEAT RISE	CFM	HEAT RISE	CFM	HEAT RISE	CFM	HEAT RISE	CFM	HEAT RISE
024K	Tap T1	755	42	706	45	637	50	598	53	548	58	520	61	520	61	450	70
	Tap T2**	894	35	852	37	804	39	760	42	707	45	661	48	661	48	574	55
	Tap T3*	1,054	30	1,013	31	978	32	932	34	896	35	839	38	839	38	755	42
	Tap T4	1,218	26	1,181	27	1,148	28	1,108	29	1,068	30	1,026	31	1,026	31	934	34
	Tap T5	1,375	23	1,341	24	1,306	24	1,270	25	1,233	26	1,199	26	1,199	26	1,120	28
030K	Tap T1	937	34	917	34	866	36	819	39	744	42	676	47	624	51	561	56
	Tap T2**	1,160	27	1,128	28	1,094	29	1,049	30	1,004	31	950	33	877	36	814	39
	Tap T3	1,292	24	1,258	25	1,216	26	1,178	27	1,124	28	1,077	29	1,022	31	963	33
	Tap T4*	1,436	22	1,400	23	1,363	23	1,324	24	1,275	25	1,226	26	1,179	27	1,125	28
	Tap T5	1,570	20	1,535	21	1,494	21	1,458	22	1,416	22	1,372	23	1,322	24	1,273	25
036K	Tap T1	1147	28	1108	29	1073	29	1,029	31	986	32	926	34	860	37	793	40
	Tap T2**	1307	24	1,276	25	1236	26	1,203	26	1,159	27	1,110	28	1,064	30	1,003	31
	Tap T3	1441	22	1,413	22	1373	23	1,339	24	1,304	24	1,248	25	1,213	26	1,163	27
	Tap T4*	1562	20	1,531	21	1503	21	1,467	22	1,432	22	1,394	23	1,351	23	1,311	24
	Tap T5	1594	20	1,559	20	1530	21	1,494	21	1,461	22	1,424	22	1,381	23	1,331	24
042K	Tap T1	1,342	24	1,301	24	1,260	25	1,221	26	1,181	27	1,139	28	1,100	29	1,055	30
	Tap T2**	1,507	21	1,465	22	1,425	22	1,388	23	1,349	23	1,310	24	1,262	25	1,227	26
	Tap T3	1,759	18	1,724	18	1,690	19	1,650	19	1,613	20	1,571	20	1,532	21	1,488	21
	Tap T4*	1,928	16	1,891	17	1,857	17	1,819	17	1,778	18	1,740	18	1,705	19	1,664	19
	Tap T5	2,047	15	2,015	16	1,982	16	1,950	16	1,912	17	1,881	17	1,836	17	1,795	18
048K	Tap T1	1,228	26	1,165	27	1,097	29	1,026	31	966	33	898	35	851	37	780	41
	Tap T2**	1,367	23	1,302	24	1,233	26	1,169	27	1,107	29	1,048	30	984	32	931	34
	Tap T3	1,479	21	1,417	22	1,354	23	1,292	24	1,232	26	1,168	27	1,101	29	1,048	30
	Tap T4*	1,590	20	1,531	21	1,479	21	1,424	22	1,357	23	1,298	24	1,238	26	1,178	27
	Tap T5	1,726	18	1,668	19	1,608	20	1,555	20	1,497	21	1,442	22	1,379	23	1,318	24
060K	Tap T1	1,576	20	1,539	21	1,502	21	1,460	22	1,417	22	1,373	23	1,339	24	1,302	24
	Tap T2**	1,736	18	1,697	19	1,663	19	1,630	19	1,593	20	1,549	20	1,513	21	1,479	21
	Tap T3	1,924	16	1,889	17	1,855	17	1,820	17	1,786	18	1,749	18	1,707	19	1,679	19
	Tap T4*	2,079	15	2,041	15	2,007	16	1,977	16	1,949	16	1,910	17	1,873	17	1,837	17
	Tap T5	2,222	14	2,197	14	2,157	15	2,129	15	2,089	15	2,058	15	2,030	16	1,988	16

* Denotes factory set COOL speed

** Denotes factory set electric HEAT speed

Temperature rises shaded gray are for reference only. These conditions are not recommended.

Table 5. Blower Data

Wiring Diagrams

WIRING DIAGRAM

Packaged Air Conditioner - Single Phase 2/2.5/3/3.5/4 Ton




Figure 12. Wiring Diagram (P95RD 2, 2.5, 3, 3.5 & 4 Ton Models)



WIRING DIAGRAM

Packaged Air Conditioner - Single Phase 5 Ton

NOTES:

1. Disconnect all power before servicing.
2. For supply connections use copper conductors only.
3. Not suitable on systems that exceed 150 V to ground.
4. For replacement wires use conductors suitable for 105° C.
5. See installation instructions for blower motor airflow settings and terminal locations.

1. Couper le courant avant de faire leretien.
2. Employez uniquement des conducteurs en cuivre.
3. Ne convient pas aux installations de plus de 150 V a la terre.



10457880
(NEW)
3/24

Figure 13. Wiring Diagram (P95RD 5 Ton Models)

INSTALLATION CHECKLIST

INSTALLATION ADDRESS:		
CITY _____	STATE _____	
UNIT MODEL # _____		
UNIT SERIAL # _____		
Unit Installed Minimum clearances per Figure 1 (page 6) ?	YES	NO
INSTALLER NAME:		
CITY _____	STATE _____	
Has the owner's information been reviewed with the customer?	YES	NO
Has the Literature Package been left with the unit?	YES	NO

REFRIGERATION SYSTEM		
Was unit given 24 hr warm up period for crankcase heaters (if equipped)?	YES	NO
Stage-1 Liquid Pressure (high side) _____		
Stage-1 Suction Pressure (low side) _____		

ELECTRICAL SYSTEM		
Electrical connections tight?	YES	NO
Line voltage polarity correct?	YES	NO
Has the thermostat been calibrated?	YES	NO
Is the thermostat level?	YES	NO
Is the leak detection sensor correct? (If Applicable)	YES	NO
Rated Voltage: _____ VOLTS		
L1-L2 Volts: _____ VOLTS		

REPLACEMENT PARTS

Replacement parts are available through your distributor. Please have the complete model and serial number of the unit when ordering replacement parts.

ELECTRICAL:

- Capacitors
- Temperature Limit Switches
- Compressors
- Thermostats
- Contactors
- Time Delay Relays
- Pressure Switches
- Transformers
- A2L Sensor

MOTORS:

- Blower Motor
- Fan Motor

COMPONENTS:

- Blower Assembly
- Fan Grille
- Cabinet Panels
- Filter/Driers
- Expansion Valves or Distributor Assembly

LEFT INTENTIONALLY BLANK

LEFT INTENTIONALLY BLANK

